Product Safety Guide (EN)

SAFETY INFORMATION



Please read the entire manual thoroughly and retain it for future reference. The company will not take any responsibility for accidents or damage resulting from careless handling by the user. CAUTION: To reduce the risk of electrical shock, do not remove the cover. No user serviceable parts inside. Refer any servicing to qualified service personnel.

1 General

1.1 Why are you receiving these instructions?

Your product is an electrical device. You should therefore take all necessary precautions to ensure complete safety when plugging the power supply cable into your device. Make sure that the power supply cable is correctly plugged into the device. If connected incorrectly, there is a risk of fire and electric shock.

1.2 Delivery scope

1. The power supply
2. HDMI cable
3. Ethernet cable
4. The remote control
5. The device itself.

You may only use the power supply supplied. Connect it to the power supply according to the instructions below. The socket should be located near the device and easily accessible.

1.3 Product label and marking

There is a rating plate under the device, and further markings are on the back. On it you will find all the information about the voltage, current and type of current for which your device is designed.

2 Installation

2.1 Requirements

Never open the power supply! There is a risk of electric shock. All work on the device must be carried out by a qualified technician. Before installing or changing connections on other devices (TV, VHS recorder, DVD player, etc.) and before cleaning your device, the device must be disconnected from the mains.

2.2 Installation environment

Optimize reception by reducing interference: Do not place the device near devices that can cause electromagnetic interference (e.g. speakers). This can affect the function of your device and lead to distortion of sound and picture.

2.3 Power supply

Only use the power supply supplied with the device. Never use any other adapter as this could result in fire, electric shock or malfunction of the device. Never place objects on the power supply. Do not step on the power supply or drive over it with an object with wheels.

Otherwise it could be damaged and cause a fire or electric shock hazard. Incorrect placement of the power adapter may result in the power supply to the device being interrupted and may result in a risk of fire or electric shock. Make sure the power adapter is out of the reach of children or pets.

Before connecting the power adapter to the device, we recommend that you connect all potential peripherals (e.g. HDMI® cable). Always plug the power supply plug into your device first, then plug the power adapter into the power outlet.
Never plug your device into a power outlet that is loose, damaged or defective. You may receive an electric shock.

Never touch the power adapter with damp or wet hands. You may receive an electric shock. When plugging or unplugging the power adapter, always hold it by the plug. A damaged cord is a potential source of fire or electric shock. Never pull on the cord to unplug the device from the power outlet.

You must connect the power adapter to the device before plugging it into the power outlet. Make sure the cord is properly inserted into the device's port. If not connected properly, touching the device may cause fire or electric shock.

Never place objects on the power adapter cable, pull on it or bend it. This may cause fire or electric shock. Always make sure that the device is not resting on the power adapter cable or any other cable.

If you hear any suspicious noises coming from the wall socket or power adapter, unplug the power adapter from the wall socket with all necessary precautions - electric shock may occur. Contact Vodafone.

2.4 The device

Install the device indoors only and protect it from direct sunlight; make sure that the device is not exposed to extreme temperatures. Use the device in an environment where the following conditions apply:

- Ambient temperature: between 0 °C and 45 °C,
- Humidity: between 20% and 90%,

Install the device and the power adapter in a dry, well-ventilated place. Protect it from moisture and dust. Connect the device to the power supply according to the instructions on its label, markings and documentation.

Use only the power adapter and cables supplied with the product.

Software updates are automatically installed on your device provided it remains connected to an active power outlet and an Internet connection is available (via Wi-Fi or network cable to the gateway).

Keep the device and the power adapter away from heat sources such as radiators or gas/electric heaters. Do not place glowing objects such as candles on or near the device.

Do not place objects such as a piece of cloth or paper over the device. If you place your device in a compartment, leave at least 10 cm of space on both sides and 20 cm in front and behind the device to avoid short circuits (with risk of fire or electric shock). Keep your device away from moisture. Do not place objects containing liquid (e.g. a vase) on the device. If any liquid comes into contact with your device (drops, splashes), it will be damaged. This may cause irreparable failure. If liquid gets into the device, immediately unplug the power cord from the socket taking all necessary precautions - electric shock may occur - and contact Vodafone.

If the product is brought into direct contact with a heat-sensitive piece of furniture, it may change its color or surface.

Devices that are connected to the protective earthing of the building installation via the main connection or via other devices and/or connected to the television distribution system via a coaxial cable may pose a fire hazard.

Please only connect other devices via the Ethernet connection that also have the same earth/ground potential in order to avoid possible equalizing currents and thus damage to the devices.

3 Using the device

3.1 The device

During a thunderstorm, we recommend that you unplug the antenna and the power supply cable. Even if the device and the TV are unplugged from the power socket, they can still be damaged by lightning.

Avoid violent mechanical shocks: Do not use the device if it is damaged. Always place your device on a flat surface where there is no risk of shaking.

Only clean the device, the power supply or the adapter with a soft, dry cloth. Never use cleaning agents or chemical additives.

3.2 The batteries or rechargeable batteries and the remote control

Your device may be supplied with a remote control and its associated batteries. Before replacing the batteries in your remote control, look in the battery compartment of the remote control. It will tell you what type of batteries (voltage, chemicals, size) you should buy to replace them.

The batteries (battery pack or built-in batteries) must not be exposed to excessive heat such as sunshine, fire or similar sources.

In any case, keep the remote control out of the reach of children: the batteries can easily be swallowed by a child. Therefore, do not leave the remote control unattended.

WARNING: Risk of fire or explosion if batteries are not replaced correctly. Replace only with the same type of battery as originally supplied.

For battery recycling, see the “Batteries” section.

3.3 Accessories

All connections are indicated in the instructions supplied with your device. You must read them before using the device.

Do not use tools or other mechanical aids to avoid damaging the connections and affecting the device’s functionality. It is possible that the connections may be damaged if you tighten them too tightly. This may cause picture and sound distortion and lead to signal loss.

If the device is equipped with a USB port: when connecting a USB peripheral, plug it in as indicated and never use force. The peripheral and/or the device may be damaged.

4 Environment

Protecting the environment is a key concern for Vodafone. Vodafone's desire is to develop environmentally conscious products. Vodafone has therefore decided to take into account eco-design criteria and restrictions from the development and manufacture, through commissioning and use, to the disposal of the product.

4.1 Packaging

European regulations require the recycling of packaging. It must not be disposed of with unsorted waste. There are local regulations for the sorting and recycling of this waste.



The circled arrow sign means that the packaging is recyclable and cannot be disposed of with regular household waste.



The logo with three arrows on the plastic parts means that they can be recycled and must not be disposed of with household waste. To facilitate recycling, please respect the sorting rules established locally for this type of waste.

4.2 The product



The crossed-out bin attached to the product or its accessories means that the product belongs to the family of electrical and electronic equipment. European regulations require you to dispose of products in the family of electrical and electronic equipment in a targeted manner

- At the collection points made available to you locally (drop-off point, selective collection, etc.),
- At points of sale when purchasing similar equipment.

In this way, you can contribute to the reuse and recovery of waste electrical and electronic equipment that can have an impact on the environment and human health.

4.3 Batteries

If your product contains batteries, these must be returned to appropriate collection points and must not be disposed of in household waste.

4.4 Power Consumption

To reduce the device's power consumption, we recommend putting it into Network Standby when you are not using it. To do so, press the "On/Off" button on the remote control. Please note that the device still consumes power in Network Standby, even if the TV does not display anything. If you do not intend to use your device for an extended period, we recommend fully turning it off and unplugging it from the socket.

When the device is disconnected from the power supply, energy consumption is reduced to zero. After the device is powered on, it may enter a maintenance mode during the startup process, which could cause a delay before the device is ready for use. Reducing energy consumption directly leads to lower operating costs.

Item	Values and details
Model No. (Power Supplies)	MN012S-E120100-10 FC012A20-120010E
Input voltage	100-240 VAC
Input Frequency	50/60 Hz
Output Voltage	12.0 VDC
Output Current	1.0 A
Output Power	12.0 W
Average Efficiency in Operation	82.96%
Power Consumption at No Load	0.1 W

- On mode : 2.76 W
- Standby Mode : 0.36 W – With network interfaces disabled
- Network Standby Mode: 1.68 W – With network connectivity maintained
- Annual total energy consumption : 16.46 kWh/year

24-hour usage scenario : On-mode 4.5 hours, network standby-mode 19.5 hours

The WLAN function can be optionally switched off via the menu.

Extending the preset time for the automatic TV switch-off function in the Android TV settings under "Settings >> Device Preferences >> Power & Energy >> Shut-Off Timer" leads to increased power consumption.

Lengthening the preset time for the automatic switch-off function (APD) or deactivating the APD function altogether can lead to an increase in energy consumption.

4.5 Name of manufacturer, commercial register number and address:

Vodafone Procurement Company S.à r.l.,
15 rue Edward Steichen, L-2540 Luxembourg, Grand-Duché de Luxembourg

VTV4 Mini is supported with software updates for 4 years to ensure compatibility with technical advancements.

Repair parts for VTV4 Mini are available for 3 years to support maintenance and longevity.

Used devices can be returned to the point of purchase or disposed of in accordance with local regulations for repair or recycling.

5 CE marking

CE We hereby declare that the product complies with Directive 2014/53/EU.

The EU declaration of conformity can be found in the support section of the Vodafone website: www.vodafone.com/vtv4mini/ce or can be obtained from the following address:

Vodafone
Vodafone Procurement Company S.à r.l.,
15 rue Edward Steichen,
L-2540 Luxembourg,
Grand-Duché de Luxembourg

5.1 Accessories and technical information

Your product, depending on the model purchased, may include:

1. The power supply
2. HDMI cable
3. Ethernet cable
4. The remote control
5. The device itself.

Use only the accessories provided.

The frequency bands used and the maximum radio frequencies transmitted in the product are as follows:

- 2400 – 2483.5 MHz: 100mW
- 5150 – 5350 MHz: 200mW
- 5470 – 5725 MHz: 1W

When the device is disconnected from the power supply, energy consumption is reduced to zero. After the device is powered on, it may enter a maintenance mode during the startup process, which could cause a delay before the device is ready for use. Reducing energy consumption directly leads to lower operating costs.

5.2 Restrictions

This radio equipment is subject to certain restrictions when placed on the market in Belgium (BE), Bulgaria (BG), Czech Republic (CZ), Denmark (DK), Germany (DE), Estonia (EE), Ireland (IE), Greece (GR), Spain (ES), France (FR), Croatia (HR), Italy (IT), Cyprus (CY), Latvia (LV), Lithuania (LT), Luxembourg (LU), Hungary (HU), Malta (MT), Netherlands (NL), Austria (AT), Poland (PL), Portugal (PT), Romania (RO), Slovenia (SI), Slovakia (SK), Finland (FI), Sweden (SE), Northern Ireland (UK(NI)), Norway (NO), Switzerland (CH), Iceland (IS), Turkey (TR), Liechtenstein (LI).

Wi-Fi 5 GHz: The 5150-5350 MHz frequency band is restricted to indoor use.

6 Licenses and Trademarks

Dolby, Dolby Vision, Dolby Atmos, Dolby Audio and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories Licensing Corporation. Confidential unpublished works. Copyright © 1992–2024 Dolby Laboratories. All rights reserved.

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Dolby VISION·ATMOS

Dolby AUDIO

HEVC Advance™ Covered by patents at patentlist.accessadvance.com