

Manual for self-installation of Super Wi-Fi



1. Connecting the main Super Wi-Fi extender:
 - 1.1 Connect the main Super Wi-Fi extender to the modem using an Ethernet cable.
 - 1.2 Plug the power cable into the power outlet and into the extender. Make sure the extender is switched on (the button on the back is pressed).
 - 1.3 Once the extender has started and established a connection (LED is solid green), the extender will start transmitting Wi-Fi.
The Wi-Fi name (Wi-Fi Name) and password (Password) can be found on the back of the extender. It is recommended to deactivate the Wi-Fi on modem according to its manual.
2. Connecting secondary Super Wi-Fi extenders:
 - 2.1 Plug the power cable into a power outlet and into the extender. (preferably within 2 meters of the main extender) Make sure the secondary extender is switched on.
 - 2.2 Once powered up (LED flashing blue), pair with the main Super Wi-Fi extender using the WPS button located on the front.
 - 2.2 a Hold the WPS button on the main Super Wi-Fi extender that is connected to the modem for 3 seconds (the LED will flash green)
 - 2.2 b Then, within 2 minutes, hold the WPS button on the secondary Super Wi-Fi extender for 3 seconds (LED flashes green)
 - 2.2 c After a successful pairing, the LED will be permanently green on both extenders. The Wi-Fi is identical to the parameters of the main extender (see point 1. 3.)
 - 2.3 Move the secondary extender to a suitable location in your home
3. The Wi-Fi settings can be adjusted in the Super Wi-Fi application.